



TEL:+1 (833) 306 1883
EST:09:00-17:00 (Monday-Friday)

MUST READ

HOW TO POWER ON YOUR FOOD PROCESSOR

Still Can't Start or Any Other Issue?
Contact us: Email support@magiccos.co

TURN OVER 



Won't Power On?




The food processor is designed with **Double Safety - Lock System**. It **ONLY START TO WORK** when both locks are correctly activated!

YouTube start guide video link: <https://youtu.be/qCd7-9sFRf4>



First Safety Lock between the bowl & the base



Step 1

- Keep the front base facing yourself and the handle of the bowl facing the Right.
- Look down at the base to find "the upper right 45 degree". Make sure the handle of the bowl is on that position.



Step 2

- Then use some strength to turn clockwise to install the bowl on the base from original position to the very **RIGHT** position.
- You **MUST HEAR** a **CLICK SOUND**, indicating that it is locked.
- Make sure to line up the indicator with the 'lock' symbol.



Second Safety Lock between the bowl & the lid



Step 3

- Install the Lid On the Bowl
- Similarly, find "the upper right 30 degree" to put the lid on the base. Turn clockwise to the **RIGHT** position.



Step 4

- Use some strength to create a **CLICK SOUND**, meaning the lid is correctly assembled on the bowl.
- Make sure to line up the indicator with the 'lock' symbol.

【Now You Can Start!】 Still can't? Contact us:  support@magiccos.co



TEL:+1 (833) 306 1883
EST:09:00-17:00 (Monday-Friday)

MUST READ

HOW TO INSTALL THE ACCESSORIES



If you meet some problems, please
contact us immediately at our email
support@magiccos.co

TURN OVER 

Chopper Blade



Place the chopper blade on the blade adaptor, once they attached firmly please put them together into the bowl.



Emusifying Disc



Place the emulsifying disc on the blade adaptor, once they attached firmly please put them together into the bowl.



Cirtus Juicer



Place the citrus juicer on the bowl, lock the citrus juicer firmly by clockwise turning the citrus juicer.



Cutting Blade



Place the cutting blade: Choose a desired blade [Slicing, Fine/Coarse grating, Wave cutting blade (Notice: Only in the latest packaging)].

Push the blade to install it on the blade holder disc, once installed together, place them on the shaft.

